
ASP HANDBOOK

QUICK FIX GUIDE 24

DOES YOUR INTERNAL FILTER NOT START OR KEEPS STOPPING?

Troubleshoot your internal filter with these 5 quick checks.

1



CHECK THE POWER

Make sure the plug is firmly inserted, the socket is working and the cable isn't damaged.


2



CHECK THE INTAKE SPONGE

Remove any debris blocking the intake or sponge. Rinse in old tank water.


3



CHECK THE IMPELLER

Unplug the filter, remove the impeller and clean away any debris. Check it spins freely and isn't worn or damaged.


4



CHECK THE WATER LEVEL

Ensure the filter is fully submerged to the recommended water level for optimal performance.

5



REASSEMBLE & TEST

Refit all parts securely, place the filter back in the tank, ensure it's fully submerged and plug it in to test.