
ASP HANDBOOK

QUICK FIX GUIDE 8

IS YOUR CANISTER FILTER NOT SEALING?

Troubleshoot your canister filter with these 5 quick checks.


1



CHECK THE LID ALIGNMENT

Ensure the lid is sitting squarely on the canister. If the lid is misaligned, it won't seal properly. Remove and refit the lid correctly.


2



CHECK THE LATCHES

Make sure all latches are closed and locked evenly. Loose or uneven latches can prevent a tight seal.


3



CHECK THE O-RING

Inspect the o-ring for damage, dirt or debris. A worn or dirty o-ring can prevent the lid from sealing.


4



CHECK THE O-RING GROOVE

Clean the groove where the o-ring sits. Any dirt, grit or grime build-up can stop the o-ring from sealing properly.

5



CHECK FOR CRACKS OR DAMAGE

Inspect the canister body and lid for any cracks or damage. Even small cracks can prevent a proper seal.