
ASP HANDBOOK

QUICK FIX GUIDE 21

IS YOUR INTERNAL FILTER LEAKING WATER?

Troubleshoot your internal filter with these 5 quick checks.

1



CHECK THE TOP SEAL

Make sure the top cover is fitted correctly and the seal is clean and in good condition.

2



CHECK THE OUTLET

Make sure the outlet and spray bar are pushed on fully and not cracked or loose.


3



CHECK THE INTAKE

Make sure the intake sponge is seated correctly and not damaged or overflowing.


4



CHECK THE MOUNTING

Ensure the suction cups are clean, in good condition and firmly attached to the tank.

5



REASSEMBLE & TEST

Refit all parts, place the filter back in the tank and check for leaks. Ensure everything is secure and operating correctly.